
# plugin 657





#### **DIRECT CONNECTION**

In order to connect to the ECU use the CABLE F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHYTE	CAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GN037C
BLU BLUE	POL5 CNF1	
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE	CHANA
MARRONE GREY	RESET	

#### **ECU CONNECTOR**




To the power feeding pins 5,19,56 (+12V) you can connect both wires red (VECU) and orange VKEY) of the F32GN037C/D cable, they both have 12V signal

### **BOOT/CNF1 CONNECTION**

Connect the GREY and BLUE wires of the cable F32GN037C/D as described here below

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	
	GRIGIO GREY	POL4 BOOT	
	BLU BLUE	POL5 CNF1	



For a correct connection on the BOOT pin of the microprocessor pad you should /we suggest to use the specific micro clamps supplied in the kit C34ACD012.

Warning: do not use other types of micro clamps, only these are completely insulated, otherwise the risk is to damage the microprocessor.

