plugin 898

DIRECT CONNECTION – ECU READING/WRITING:

For the READING&WRITING procedure use the cable F34NTA13 directly connected to the ECU.
Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION
MARRONE BROWN		BOOT
BLU BLUE		CNF
NERO BLACK	GIALLO YELLOW	RXD
OR		
GIALLO YELLOW		
GRIGIO GREY	VERDE GREEN	TXD
ROSSO RED		POSITIVO DIRETTO POWER BATTERY
NERO BLACK		MASSA GND

GND   RXD   TXD   CNF1