plugin 316 SUZUKI-FIAT



ECU TYPE 1




ECU TYPE 2




DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO	DESCRIZIONE	
WIRE COLOUR	DESCRIPTION	
ROSSO	POSITIVO DIRETTO	
RED	POWER BATTERY	
ARANCIO	POSITIVO SOTTO QUADRO	
ORANGE	POWER SWITCH ON	
NERO	MASSA	
BLACK	GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	CAN HIGH	
GRIGIO	POL4	
GREY	BOOT	
BLU	POL5	
BLUE	CNF1	
VIOLA/GRIGIO	TENSIONE PROG.	
PURPLE/GREY	PROG. VOLTAGE	
MARRONE BROWN	RESET	



ECU CONNECTOR



WARNING:


on this ECU you must use two different flat cables: one is for the READING procedure and one is for the WRITING procedure.

DIRECT CONNECTION – ECU READING:

For the READING procedure use the FLAT cable F34NTF53

	11 25 12 26	
Pin	Colore	
25.50	Colour	
11	Non usato	
TARRAY AND A STATE OF THE STATE	Not used Non usato	
1.2	Non usato Not used	
THE STATE OF THE S	Not used Non usato	
13	Not used	
4004	Non usato	
14	Not used	
15	Non usato	
15	Not used	
16	Blu	
10	Blue	
17	Viola	
196	Violet	
18	Grigio Grey	
9350 223	Bianco	
19	White	
20	Nero	
20	Black	
21	Marrone Brown	
22	Rosso	
900	Red	
23	Arancio	
20.00	Orange Giallo	
24	Yellow	
25	Verde	
25	Green	
26	Non usato Not used	


For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use a fine grit glass-paper smoothing by gentle pressure the connection of the lay by pins. In order to read the ECU it is necessary to set a 2.2 K0hm resistor and to link the 2 pads as shown in the pictures here below. Remove the 2.2 K0hm resistor and the link at the end of the reading.



LINK ECU TYPE 1



LINK ECU TYPE 2



DIRECT CONNECTION – ECU WRITING:

For the WRITING procedure use the FLAT cable F34NTF51

1 3 9 2 4 10		
Pin	Colore	
12000	Colour	
1	Marrone	
.	Brown	
2	Non usato	
s 5 2.	Not used	
3	Non usato	
	Not used Giallo	
4	Yellow	
_	Verde	
5	Green	
6	Blu	
6	Blue	
7	Viola	
	Violet	
8	Grigio	
	Grey	
9	Bianco	
	White	
10	Nero Black	
× 55.00	Black	

For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use a fine grit glass-paper smoothing by gentle pressure the connection of the lay by pins.

