
PLUGIN 644








DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	
	ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
18	ARANCIO DRANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
100	NERO BLACK	MASSA GND	
100	GIALLO /ELLOW	KLINE	
1 85	/ERDE GREEN	CAN LOW	
100	SIANCO VHITE	ICAN HIGH	
	RIGIO GREY	POL4 BOOT	
1.0	SLU BLUE	POL5 CNF1	
3 -	/IOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE	
	MARRONE BROWN	RESET	



ECU CONNECTOR



WARNING:


on this ECU you must use two different flat cables: one is for the READING procedure and one is for the WRITING procedure

DIRECT CONNECTION - ECU READING:


For the READING procedure use the FLAT cable F34NTF53

	A STATE OF THE PARTY OF THE PAR	
Die	Colore	
Pin	Colour	
4.4	Non usato	
11	Not used	
12	Non usato	
新 德 。	Not used	
13	Non usato	
	Not used Non usato	
14	Non usato Not used	
20 mm	Not used Non usato	
15	Not used	
16	Blu	
16	Blue	
17	Viola	
±1.	Violet	
18	Grigio	
	Grey	
19	Bianco White	
8-8451	Nero	
20	Black	
21	Marrone Brown	
5.5	Rosso	
22	Red	
23	Arancio	
51 W	Orange Giallo	
24	Giallo Yellow	
C00100	Verde	
25	Green	
26	Non usato	
20	Not used	

To get access to the lower side of the ECU board you must desolder the 4 PINS shown in the picture here below, otherwise you will not be able to detach the board from the cover.



For a correct soldering procedure clean very well the soldering lay by pins from the plastic film. We suggest you to use a fine grit glass paper smoothing by gentle pressure the connection of the lay by pins. For the reading procedure it is necessary to perform all the 4 LINK shown in the picture here below. At the end of the reading procedure remove all the LINK.



DIRECT CONNECTION - ECU WRITING:

For the WRITING procedure use the FLAT cable F34NTF51

1 3 9 10		
Pin	Colore Colour	
1	Marrone Brown	
2.	Non usato Not used	
3	Non usato Not used	
4	Giallo Yellow	
5	Verde Green	
6	Blu Blue	
7	Víola Violet	
8	Grigio Grey	
9	Bianco White	
10	Nero Black	

For a correct soldering procedure clean very well the soldering lay by pins from the plastic film. We suggest you to use a fine grit glass paper smoothing by gentle pressure the connection of the lay by pin.

