
plugin **127, 549**



DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON Do NOT use this connection with the METAL POSITIONING FRAME CONNECTION.


COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	CAN HIGH	
GRIGIO GREY	POL4 BOOT	F320/037C
BLU BLUE	POL5 CNF1	
	TENSIONE PROG. PROG. VOLTAGE	CHARLES .
MARRONE BROWN	RESET	



BOOT/POL4 CONNECTION

Connect the GREY wire of the cable F32GN037C as described here below :

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	
GRIC GRE		POL4 BOOT	



METAL POSITIONING FRAME CONNECTION CONNECTION

Connect the boot pin to the pad n.10 of the soldering lay-by pins.

