BOSCH EDC7 C1/C2

plugin 31-58-59-129-134-383-791-1037-1129

The lay-by pins are placed in the lower part of the ECU.



BOSCH EDC7 C1/C2


ECU CONNECTOR

In order to connect to the ECU use the CABLE F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	ICAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GH037C
BLU BLUE	POL5 CNF1	
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE	- CHANNE
MARRONE BROWN	RESET	

DIRECT CONNECTION

For the direct connection it is required the soldering adapter F34NTA06, please verify the PIN 1 of the board matches with the PIN 1 of the adapter.



BOSCH EDC7 C1/C2

METAL POSITIONING FRAME CONNECTION

For the metal positioning frame connection is required the adapter F34DM003 + F34DM008, please check that the 2 adapters are properly connected as shown here below.

