


BOSCH EDC7 C1 MAN





DIRECT CONNECTION

Use adapter SIEMENS F34FL006 for direct connection



BOSCH EDC7 C1 MAN

DIMA CONNECTION

To connect with DIMA you need adaptor F34DM008

