

## BOSCH EDC7C32 XROM MPC562 EGPT MAN

1434 BOSCH EDC7C32 XROM MPC562 EGPT MAN

**ATTENZIONE:** per comunicare correttamente con la centralina, è obbligatorio utilizzare il cavo **F34NTA22-S8**.


**WARNING:** for correct communication with the ECU, it is mandatory to connect the cable **F34NTA22-S8**.

**ATTENTION:** pour une communication correcte avec l'ECU, il est obligatoire de connecter le câble **F34NTA22-S8**.


**ATENCIÓN:** para una correcta comunicación con la ECU, es obligatorio conectar el cable **F34NTA22-S8**.

**ATENÇÃO:** para uma comunicação correcta com a ECU, é obrigatório ligar o cabo **F34NTA22-S8**.


**F34NTA22-S8**



BOSCH EDC7C32 XROM MPC562 EGPT MAN



=



BOSCH EDC7C32 XROM MPC562 EGPT MAN

ECU CONNECTOR / CONNETTORE ECU / CONNECTEUR ECU  
ECU VERBINDUNG / CONECTOR ECU

