





BOSCH EDC7U31

To get access to the lay-by pin it is necessary to unstuck the board from the covers.



BOSCH EDC7U31

DIRECT CONNECTION



BOSCH EDC7U31

DIMA CONNECTION

