# BOSCH ME17.8.8 IROM TC1728 BAIC

plugin **1007**

# BOSCH ME17.8.8 IROM TC1728 BAIC

BOSCH ME17.8.8 IROM TC1728 BAIC

ECU CONNECTOR

In order to connect to the ECU use the CABLE F32GN037C.
Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION
	ROSSO RED	POSITIVO DIRETTO POWER BATTERY
	ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
	NERO BLACK	MASSA GND
	GIALLO YELLOW	KLINE
	VERDE GREEN	CAN LOW
	BIANCO WHITE	CAN HIGH
	GRIGIO GREY	POL4 BOOT
	BLU BLUE	POL5 CNF1
	VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE
	MARRONE BROWN	RESET

PIN 01 = CAN H
PIN 17 = CAN L
PIN 20, 35 = +12V
PIN 64 = GND

BOSCH ME17.8.8 IROM TC1728 BAIC

CNF1 DIRECT CONNECTION

Connect the BLUE wire of the cable F32GN037C as described here below:

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION
	BLU BLUE	CNF1