BOSCH ME7.9.10 FIAT

plugin 024

The lay-by pins are placed in the lower part of the ECU.



DIRECT CONNECTION


In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.

DO NOT USE THIS CONNNECTION WITH THE METAL POSITIONING FRAME

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	CAN HIGH	
GRIGIO GREY	POL4 BOOT	FSZONOSTC
BLU BLUE	POL5 CNF1	Bonna Mills
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE	WHATHA
MARRONE BROWN	RESET	

BOSCH ME7.9.10 FIAT


ECU CONNECTOR



BOOT&CNF1 CONNECTION

Connect the BLUE and GREY wires of the cable F32GN037C as described here below:

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	
	GRIGIO GREY	POL4 BOOT	
	BLU BLUE	POL5 CNF1	



BOSCH ME7.9.10 FIAT

METAL POSITIONING FRAME CONNECTION

Warning: the ECU is fed through the flat cable connected to the METAL POSITIONING FRAME, it is NOT necessary to feed directly the ECU through the main connector.



