
PLUGIN 416



ECU CONNECTOR

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	CAN HIGH	
GRIGIO GREY	POL4 BOOT	F310/037C
BLU BLUE	POL5 CNF1	16/19
	TENSIONE PROG. PROG. VOLTAGE	- CHARLES
MARRONE BROWN	RESET	



DIRECT CONNECTION



DIMA CONNECTION

Connect the boot pin to the programming lay by pin n. 10.

