plugin 385

Warning: there are 2 different ECU HW types

HW TYPE 01







DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.


| COLORE FILO WIRE COLOUR | | DESCRIZIONE DESCRIPTION |
|----------------------------|-------------------|--|
| | ROSSO RED | POSITIVO DIRETTO POWER BATTERY |
| | ARANCIO ORANGE | POSITIVO SOTTO QUADRO POWER SWITCH ON |
| | NERO BLACK | MASSA GND |
| | GIALLO YELLOW | KLINE |
| | VERDE GREEN | CAN LOW |
| | BIANCO WHITE | ICAN HIGH |
| 55 | GRIGIO GREY | POL4 BOOT |
| | BLU BLUE | POL5 CNF1 |
| | | TENSIONE PROG. PROG. VOLTAGE |
| | MARRONE BROWN | RESET |



ECU CONNECTOR: connector A



F34NTA11 ADAPTER CONNECTION











LOOSE WIRES CONNECTION:

Connect the flat cable F34NTF53 as shown here below:






HW TYPE 02



DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.


| COLORE FILO WIRE COLOUR | DESCRIZIONE DESCRIPTION POSITIVO DIRETTO POWER BATTERY |
|----------------------------|--|
| ROSSO RED | |
| ARANCIO ORANGE | POSITIVO SOTTO QUADRO POWER SWITCH ON |
| NERO BLACK | MASSA GND |
| GIALLO YELLOW | KLINE |
| VERDE GREEN | CAN LOW |
| BIANCO WHITE | ICAN HIGH |
| GRIGIO GREY | POL4 BOOT |
| BLU BLUE | POL5 CNF1 |
| | TENSIONE PROG. PROG. VOLTAGE |
| MARRONE BROWN | RESET |



ECU CONNECTOR: connector A




F34NTA11 ADAPTER CONNECTION









LOOSE WIRES CONNECTION:

Connect the flat cable F34NTF53 as shown here below:

