

CONTINENTAL ACM2.1 IROM TC1796 MEB TRUCK

plugin 1029

The required cable for the correct communication is F34NTA20.

WARNING: Trasdata software might show the message " [E100082] Power output error" while communicating with the ECU.

In this case, it's NECESSARY to power the ECU at 12V in order to read it correctly

WARNING: for a correct communication both vehicle connectors must be disconnected from the ECU. Connect first the cable to the Trasdata, then to the ECU, ONLY after you can connect the power to the Trasdata.

At the end of the communication procedures detach first power from the Trasdata and then the ECU connector.

F34NTA20



CONTINENTAL ACM2.1 IROM TC1796 MEB TRUCK

