

plugin 1030

The required cable for the correct communication is F34NTA19.

WARNING: Trasdata software might show the message " [E100082] Power output error" while communicating with the ECU.

In this case, it's NECESSARY to power the Trasdata at 12V in order to read it correctly

WARNING: for a correct communication both vehicle connectors must be disconnected from the ECU. Connect first the cable to the Trasdata, then to the ECU, ONLY after you can connect the power to the Trasdata.

At the end of the communication procedures detach first power from the Trasdata and then the ECU connector.

F34NTA19



CONTINENTAL MCM2.1 IROM TC1797 MEB TRUCK

