
#### CONTINENTAL SIM2K 240R IROM TC1767 HYUNDAI KIA

## plugin 1497

# **ENGINE ECU** management



## CONTINENTAL SIM2K 240R IROM TC1767 HYUNDAI KIA




#### CONTINENTAL SIM2K 240R IROM TC1767 HYUNDAI KIA

#### ECU CONNECTOR

In order to connect to the ECU use the cable F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	ICAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GN097C
BLU BLUE	POL5 CNF1	
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE	- SHARES
MARRONE BROWN	RESET	



To the power feeding pins 5,41,58 (+12V) you can connect both wires red (VECU) and orange (VKEY) of the F32GN037C/D cable, they both have 12V signal.

# **DIRECT BOOT/CNF1 CONNECTION**

Connect the GREY&BLUE wires of the cable F32GN037C/D as described here below:

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	
	GRIGIO GREY	воот	
	BLU BLUE	CNF1	

