
plugin **1106**



ECU TYPE 1 1 processor




ECU TYPE 2 2 processors



CONNECTOR ECU TYPE 1&2

In order to connect to the ECU use the cable F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	ICAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GH037C
BLU BLUE	POL5 CNF1	December 1
	TENSIONE PROG. PROG. VOLTAGE	CHILD
MARRONE BROWN	RESET	



DIRECT BOOT/CNF1/RESET CONNECTION ECU TYPE 1

Connect the GREY, BLUE & BROWN wires of the cable F32GN037C as described here below:

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	
	GRIGIO GREY	воот	
	BLU BLUE	CNF1	
5	MARRONE BROWN	RESET	

Warning:in order to read&write properly the ECU it is necessary to perform a LINK, remove it before placing back the ECU into the vehicle.



DIRECT BOOT/CNF1/RESET CONNECTION ECU TYPE 2

Connect the GREY, BLUE & BROWN wires of the cable F32GN037C as described here below:

SECTION AND DESCRIPTION	RE FILO COLOUR	DESCRIZIONE DESCRIPTION	
	GRIGIO GREY	воот	
	BLU BLUE	CNF1	
E.	MARRONE BROWN	RESET	

Warning:in order to read&write properly the ECU it is necessary to perform a LINK, remove it before placing back the ECU into the vehicle.

