
plugin 079
The Lay-by pins are placed in the lower-left part of the ECU, as shown in the picture.




ECU CONNECTOR


In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.


COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION
	ROSSO RED	POSITIVO DIRETTO POWER BATTERY
	ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
	NERO BLACK	MASSA GND
	GIALLO YELLOW	KLINE
	VERDE GREEN	CAN LOW
8	BIANCO WHITE	ICAN HIGH
at 50	GRIGIO GREY	POL4 BOOT
	BLU BLUE	POL5 CNF1
		TENSIONE PROG. PROG. VOLTAGE
	MARRONE BROWN	RESET






DIRECT CONNECTION with DELPHI F34NTA03 adapter







DIMA CONNECTION

Use the F34DM001 DIMA adapter as shown in the following pictures

