


DELPHI PCX2 MPC5566 DAF PACCAR


plugin 509 - 623



DELPHI PCX2 MPC5566 DAF PACCAR

OPENING ECU SUGGESTION

In order to open the ECU we suggest you to use a press as shown in the picture here below. It is very important to hold the connectors of the ECU as you keep levering on the ECU cover.





DELPHI PCX2 MPC5566 DAF PACCAR

DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C/D.
Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
ROSSO RED	POSITIVO DIRETTO POWER BATTERY
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
NERO BLACK	MASSA GND
GIALLO YELLOW	KLINE
VERDE GREEN	CAN LOW
BIANCO WHITE	CAN HIGH
GRIGIO GREY	POL4 BOOT
BLU BLUE	POL5 CNF1
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE
MARRONE BROWN	RESET





DELPHI PCX2 MPC5566 DAF PACCAR

J-TAG free wires connection

Connect the cable F34NTF53 as shown here below:

Pin	Colore Colour
11	Non usato Not used
12	Non usato Not used
13	Non usato Not used
14	Non usato Not used
15	Non usato Not used
16	Blu Blue
17	Viola Violet
18	Grigio Grey
19	Bianco White
20	Nero Black
21	Marrone Brown
22	Rosso Red
23	Non usato Not used
24	Giallo Yellow
25	Non usato Not used
26	Non usato Not used



DELPHI PCX2 MPC5566 DAF PACCAR

WARNING: connect the wires avoiding any short circuits among the pads.

