# DENSO M32R196 32920-17K92 SUZUKI


# plugin 1061 ENGINE control management plugin 1062 TRACTION control management




# DENSO M32R196 32920-17K92 SUZUKI

#### **DIRECT CONNECTION**

In order to connect to the ECU use the cable F34NTA13. Make sure that the POWER led (red) on Trasdata is ON.



# **ECU CONNECTOR plugin 1061**



# **ECU CONNECTOR plugin 1062**

