plugin 533



DIRECT CONNECTION READING/WRITING ECU:

In order to connect to the ECU use the CABLE F34NTA13. Make sure that the POWER led (red) on Trasdata is ON

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	F34NTA13
MARRONE BROWN		воот	SPORT WWW.dimpert.com
BLU BLUE		CNF	
NERO GIALLO YELLOW OR		RXD	
GIALLO YELLOW		KAD	
GRIGIO GREY	VERDE GREEN	TXD	
ROSSO RED		POSITIVO DIRETTO POWER BATTERY	
NERO BLACK		MASSA GND	

ECU CONNECTOR

