## DENSO SH7054 32920-24FXX SUZUKI

## plugin 672



## DENSO SH7054 32920-24FXX SUZUKI

## DIRECT CONNECTION

In order to connect to the ECU use the F34NTA13 wiring Make sure that the POWER led (red) on Trasdata is ON.

| COLORE FILO<br>WIRE COLOUR                            |                | DESCRIZIONE<br>DESCRIPTION        | F34NTA13   |
|---|----------------|-----------------------------------|--|
| MARRONE<br>BROWN                                      |                | BOOT                              |  |
| BLU<br>BLUE   |                | CNF                               |  |
| NERO GIALLO<br>BLACK YELLOW<br>OR<br>GIALLO<br>YELLOW |                | RXD                               | and and a second s |
| GRIGIO<br>GREY  | VERDE<br>GREEN | TXD                               |  |
| ROSSO<br>RED  |                | POSITIVO DIRETTO<br>POWER BATTERY |  |
| NERO<br>BLACK   |                | MASSA<br>GND                      |  |

