

DENSO SH7054 32920-30Gxx SUZUKI

plugin 526



DIRECT CONNECTION – ECU READING e WRITING:

Use the cable F34NTA13 directly connected to the ECU.
 Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
MARRONE BROWN	BOOT
BLU BLUE	CNF
NERO BLACK	RXD
GIALLO YELLOW	
OR	
GIALLO YELLOW	
GRIGIO GREY	TXD
VERDE GREEN	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY
NERO BLACK	MASSA GND

