

DENSO SH7054 3C3 8591A YAMAHA

plugin 557



DENSO SH7054 3C3 8591A YAMAHA

DIRECT CONNECTION READING/WRITING ECU:

In order to connect to the ECU use the CABLE F34NTA13.
Make sure that the POWER led (red) on Trasdata is ON

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
MARRONE BROWN	BOOT
BLU BLUE	CNF
NERO BLACK	RXD
GIALLO YELLOW	
OR	
GIALLO YELLOW	
GRIGIO GREY	TXD
VERDE GREEN	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY
NERO BLACK	MASSA GND



ECU CONNECTOR

