

plugin 1005,1372,1421






ECU CONNECTOR

In order to connect to the ECU use the cable F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.



ECU CONNECTOR



To the power feeding pins 3,50,88 (+12V) you can connect both wires red (VECU) and orange VKEY) of the F32GN037C/D cable, they both have 12V signal.

DIRECT BOOT CONNECTION

Connect the GREY wire of the cable F32GN037C/D as described here below:

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION	
	GRIGIO GREY	POL4 BOOT	

