

1 MITSUBISHI E6T85771 MH8611 MITSUBISHI

1.1 PLUGIN 1662



1.2 DIRECT CONNECTION

In order to connect to the ECU use the cable F32GN037C/D .
 Make sure that the POWER led (red) on TRASDATA is ON.

| WIRE COLOUR | DESCRIPTION |
|---------------|-------------|
| Red | +12 V |
| Orange | VKEY |
| Black | GND |
| Yellow | KLIN |
| Green | CAN L |
| White | CAN H |
| Grey | BOOT |
| Blue | CNF1 |
| Purple - Grey | VPP |
| Brown | RESET |



1.3 ECU CONNECTOR

