MITSUBISHI MH5xxxF F8T820XXX YAMAHA

plugin 686






MITSUBISHI MH5xxxF F8T820XXX YAMAHA

ECU CONNECTOR

For the connection with LOOSE WIRES use the cable F32GN037C/D connected to the ECU. Make sure that the POWER led (red) on Trasdata is ON



ECU CONNECTOR

