
MITSUBISHI MH8102F 6P2-8591A-25 YAMAHA

plugin 1637



DIRECT CONNECTION

For the connection with LOOSE WIRES use the cable F32GN037C/D connected to the ECU. Make sure that the POWER led (red) on Trasdata is ON



ECU CONNECTOR

