MITSUBISHI MH8115F 33920-96L10 SUZUKI

plugin 896






MITSUBISHI MH8115F 33920-96L10 SUZUKI

DIRECT CONNECTION

For the connection with LOOSE WIRES use the cable F32GN037C/D connected to the ECU. Make sure that the POWER led (red) on Trasdata is ON.



ECU CONNECTOR

