## MITSUBISHI MH8115F 8KJ-8591A-XX ARCTIC CAT


# plugin 899



### MITSUBISHI MH8115F 8KJ-8591A-XX ARCTIC CAT

#### **DIRECT CONNECTION**

For the connection with LOOSE WIRES use the cable F32GN037C/D connected to the ECU. Make sure that the POWER led (red) on Trasdata is ON.



#### **ECU CONNECTOR**

