
MITSUBISHI MH8115F E6T91695H SUZUKI

plugin **897**






MITSUBISHI MH8115F E6T91695H SUZUKI

DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.



ECU CONNECTOR

