## MITSUBISHI MH8305F MITSUBISHI COLT

## PLUGIN 255, 329

## **DIRECT CONNECTION**

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	ICAN HIGH	
GRIGIO GREY	POL4 BOOT	F320037C
BLU BLUE	POL5 CNF1	Passantill 1
VIOLA/GRIGIO PURPLE/GREY	P TENSIONE PROG. PROG. VOLTAGE	WARNE
MARRONE BROWN	RESET	

## ECU CONNECTOR



To the 3 power feeding pins you can connect both wires red and orange, they both have 12 Volt signal.