plugin 826 WARNING:

this ECU is dedicated to the aftertreatment control.

There are some types of ECU equipped with a protected microcontroller that at the moment is not supported.





ECU CONNECTOR

In order to connect to the ECU use the CABLE F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	CAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GN037C
BLU BLUE	POL5 CNF1	[694]
VIOLA/GRIG PURPLE/GRE	IO TENSIONE PROG. Y PROG. VOLTAGE	THE PARTY OF THE P
MARRONE BROWN	RESET	



F34NTA03 adapter connection





