
plugin 1664

TYPE 01: SIMOS 15.25




TYPE 02: SIMOS15.27





DIRECT CONNECTION

In order to connect to the ECU use the cable F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.




ECU CONNECTOR SIMOS15.25 & SIMOS15.27



DIRECT CNF1 CONNECTION TYPE 01 SIMOS15.25

Connect the BLUE wire of the cable F32GN037C/D as described here below

COLORE FILO	DESCRIZIONE
WIRE COLOUR	DESCRIPTION
BLU BLUE	CNF1



DIRECT CNF1 CONNECTION TYPE 02 SIMOS15.27

Connect the BLUE wire of the cable F32GN037C/D as described here below

RE FILO COLOUR	DESCRIZIONE DESCRIPTION	
BLU BLUE	CNF1	

Warning: LINK1, LINK2, are mandatory connections for a correct communication. Remove the LINKS before placing the ECU back into the vehicle.

