

VALEO V46.xx SH72544 JTAG PSA

plugin 1722-1723-1779



VALEO V46.xx SH72544 JTAG PSA




VALEO V46.xx SH72544 JTAG PSA




VALEO V46.xx SH72544 JTAG PSA



VALEO V46.xx SH72544 JTAG PSA



VALEO V46.xx SH72544 JTAG PSA




VALEO V46.xx SH72544 JTAG PSA

DIRECT CONNECTION

For the connection use the cable F32GN037C/D connected to the ECU.
Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION
ROSSO RED		POSITIVO DIRETTO POWER BATTERY
ARANCIO ORANGE		POSITIVO SOTTO QUADRO POWER SWITCH ON
NERO BLACK		MASSA GND
GIALLO YELLOW		KLINE
VERDE GREEN		CAN LOW
BIANCO WHITE		ICAN HIGH
GRIGIO GREY		POL4 BOOT
BLU BLUE		POL5 CNF1
VIOLA/GRIGIO PURPLE/GREY		TENSIONE PROG. PROG. VOLTAGE
MARRONE BROWN		RESET





ECU CONNECTOR



VALEO V46.xx SH72544 JTAG PSA

J-TAG LOOSE WIRES CONNECTION

For the reading & writing procedures use the FLAT cable F34NTF53



Pin	Colore Colour
11	Non usato Not used
12	Non usato Not used
13	Non usato Not used
14	Non usato Not used
15	Non usato Not used
16	Blu Blue
17	Viola Violet
18	Grigio Grey
19	Bianco White
20	Nero Black
21	Marrone Brown
22	Rosso Red
23	Arancio Orange
24	Giallo Yellow
25	Verde Green
26	Non usato Not used

VALEO V46.xx SH72544 JTAG PSA

Connect the wires on the pads avoiding any short circuits.

