


BOSCH EDC17CP51 CM3230B TC1797 IROM NISSAN

plugin 1370



BOSCH EDC17CP51 CM3230B TC1797 IROM NISSAN



BOSCH EDC17CP51 CM3230B TC1797 IROM NISSAN


DIRECT CONNECTION

In order to connect to the ECU use the cable F32GN037C.


Make sure that the POWER led (red) on Trasdata is ON.

Do not use this connection with the metal positioning frame kit, it will be the F34DM011 adapter to power the ECU.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
ROSSO RED	POSITIVO DIRETTO POWER BATTERY
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
NERO BLACK	MASSA GND
GIALLO YELLOW	KLINE
VERDE GREEN	CAN LOW
BIANCO WHYTE	CAN HIGH
GRIGIO GREY	POL4 BOOT
BLU BLUE	POL5 CNF 1
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE
MARRONE GREY	RESET



ECU CONNECTOR




BOSCH EDC17CP51 CM3230B TC1797 IROM NISSAN

DIRECT BOOT CONNECTION

Connect the GREY wire of the cable F32GN037C as described here below:

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
GRIGIO GREY	POL4 BOOT




BOSCH EDC17CP51 CM3230B TC1797 IROM NISSAN

METAL POSITIONING FRAME CONNECTION

For the metal positioning frame connection is required the F34DM011 adapter.

WARNING: for the F34DM011 adapter positioning do not use the pads on the left side of the picture as shown here below

Connect the BOOT pins to the pad n.10 of the soldering lay-by pins then verify that the switch BOOT present on the F34DM011 is set in position ON.



A different solution is to connect the BOOT wire directly to the orange BOOT clamp on the F34DM011 adapter. Check that the yellow BOOT jumper is set in ON position. Connect then the flat cable to the Trasdata.

The following picture of the F34DM011 adapter connection is merely indicative.

