

# BOSCH MED17.1.6 IROM TC1797 GPT VAG

plugin 690 BOSCH MED17.1.6 IROM TC1797 GPT VAG

## GPT CONNECTION

To perform the GPT connection it is necessary to use both the ANALOG PORT and the DIGITAL PORT.

### GPT connection with loose wires


Connect the F32GN037 cable to the **ANALOG PORT**

Connect the F34NTF53 cable to the **DIGITAL PORT**, ONLY the wire 23 (ORANGE) and wire 24 (YELLOW) will be used as shown in the following picture

### GPT connection with DIMA

Connect the F32GN038 cable to the **ANALOG PORT**

Connect the F34NTF53 cable to the **DIGITAL PORT** ONLY the wire 23 (ORANGE) and wire 24 (YELLOW) will be used as shown in the following picture



BOSCH MED17.1.6 IROM TC1797 GPT VAG

MED17.1.6



# BOSCH MED17.1.6 IROM TC1797 GPT VAG



## ECU CONNECTOR

In order to connect to the ECU use the CABLE F32GN037C.

Make sure that the POWER led (red) on Trasdata is ON.

Do not use this connection with the KIT DIMA.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
ROSSO RED	POSITIVO DIRETTO POWER BATTERY
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
NERO BLACK	MASSA GND
GIALLO YELLOW	KLINE
VERDE GREEN	CAN LOW
BIANCO WHITE	CAN HIGH
GRIGIO GREY	POL4 BOOT
BLU BLUE	POL5 CNF1
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE
MARRONE BROWN	RESET




## BOSCH MED17.1.6 IROM TC1797 GPT VAG

### BOOT CONNECTION

Connect the GREY wire of the cable F32GN037C as shown in the picture.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
GRIGIO	POL4
GREY	BOOT




## BOSCH MED17.1.6 IROM TC1797 GPT VAG

### GPT CONNECTION

Connect the GPT S1 & GPT S2 pins to the specific wires of the F34NTF53 flat cable as shown in the following picture

PIN / Colore PIN / Coulor	DESCRIZIONE DESCRIPTION
23	GPT_S2
24	GPT_S1



## BOSCH MED17.1.6 IROM TC1797 GPT VAG

### **DIMA & DIMA BNP CONNECTION**

For the DIMA connection is required the F34DM011 DIMA adapter + the F32GN038 flat cable. Connect the F34NTF53 flat cable to the DIGITAL PORT, connect the F32GN038 FLAT cable to the ANALOG PORT and to the F34DM011 DIMA adapter. Then perform the BOOT connection using the BOOT clamp on the DIMA adapter, verify that the switch BOOT present on the F34DM011 is set in position ON. Perform GPT connections as shown in the previous detail at pg.5 and as in the following picture.

