

CONTINENTAL SDI3 IROM TC1796 SSM BENCH PORSCHE

plugin 1561




CONTINENTAL SDI3 IROM TC1796 SSM BENCH PORSCHE

**DIRECT CONNECTION**

In order to connect to the ECU use the cable F32GN037C/D.  
 Make sure that the POWER led (red) on Trasdata is ON.

| COLORE FILO<br>WIRE COULOR  | DESCRIZIONE<br>DESCRIPTION               |
|-----------------------------|--|
| ROSSO<br>RED                | POSITIVO DIRETTO<br>POWER BATTERY        |
| ARANCIO<br>ORANGE           | POSITIVO SOTTO QUADRO<br>POWER SWITCH ON |
| NERO<br>BLACK               | MASSA<br>GND                             |
| GIALLO<br>YELLOW            | KLINE                                    |
| VERDE<br>GREEN              | CAN LOW                                  |
| BIANCO<br>WHYTE             | CAN HIGH                                 |
| GRIGIO<br>GREY              | POL4<br>BOOT                             |
| BLU<br>BLUE                 | POL5<br>CNF1                             |
| VIOLA/GRIGIO<br>PURPLE/GREY | TENSIONE PROG.<br>PROG. VOLTAGE          |
| MARRONE<br>GREY             | RESET                                    |



Due to the relevant power absorbed by the ECU at the beginning of the communication it is necessary to feed the ECU with an external power supply or a car battery. Connect the power cable F32GN003 to the Trasdata and then to the power source. The ECU must be powered through the Trasdata using the F32GN037C/D cable.



CONTINENTAL SDI3 IROM TC1796 SSM BENCH PORSCHE

## ECU CONNECTOR

