

DELPHI DCM3.7 VAG


plugin **389,862**



DELPHI DCM3.7 VAG




DELPHI DCM3.7 VAG




## DELPHI DCM3.7 VAG

In order to connect to the ECU use the CABLE F32GN037C.  
Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
<span style="color: red;">■</span> ROSSO RED	POSITIVO DIRETTO POWER BATTERY
<span style="color: orange;">■</span> ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
<span style="color: black;">■</span> NERO BLACK	MASSA GND
<span style="color: yellow;">■</span> GIALLO YELLOW	KLINE
<span style="color: green;">■</span> VERDE GREEN	CAN LOW
<span style="color: white;">■</span> BIANCO WHITE	CAN HIGH
<span style="color: grey;">■</span> GRIGIO GREY	POL4 BOOT
<span style="color: blue;">■</span> BLU BLUE	POL5 CNF1
<span style="color: purple;">■</span> VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE
<span style="color: brown;">■</span> MARRONE BROWN	RESET



### ECU CONNECTOR




To the power feeding pins 3,87,92 (+12V) you can connect both wires red (VECU) and orange (VKEY) of the F32GN037C cable, they both have 12V signal.

## DELPHI DCM3.7 VAG

### **WARNING:**

in order to work it is necessary to remove both ECU layers and perform the 6 bridges (LINK) on the lower side of the ECU. Then close it with all the screws, place it back into the vehicle and verify that the vehicle runs fine without any warning lights.

The 6 bridges (LINK) can be definitively left on the ECU without removing them.





## DELPHI DCM3.7 VAG

### DIRECT CONNECTION – ECU READING:


For the READING procedure use the FLAT cable F34NTF53

Pin	Colore Colour
11	Non usato Not used
12	Non usato Not used
13	Non usato Not used
14	Non usato Not used
15	Non usato Not used
16	Non usato Not used
17	Non usato Not used
18	Grigio Grey
19	Bianco White
20	Nero Black
21	Marrone Brown
22	Rosso Red
23	Arancio Orange
24	Giallo Yellow
25	Verde Green
26	Non usato Not used



## DELPHI DCM3.7 VAG



Connect the wires 18,19,20,21,22,23,24,25 avoiding any short circuit among the pads.



## DELPHI DCM3.7 VAG

### DIRECT CONNECTION – ECU WRITING:

For the WRITING procedure use the FLAT cable F34NTF51



Pin	Colore Colour
1	Non usato Not used
2	Non usato Not used
3	Non usato Not used
4	Non usato Not used
5	Verde Green
6	Blu Blue
7	Viola Violet
8	Grigio Grey
9	Non usato Not used
10	Non usato Not used



## DELPHI DCM3.7 VAG

Connect the wires 5,6,7,8 avoiding any short circuit among the pads.

