


DELPHI DCM7.1A TC297TP IROM PSA

plugin 1545 DELPHI DCM7.1A TC297TP IROM PSA

plugin 1661 DELPHI DCM7.1B TC297TP 96 OPEL/PSA/TOYOTA



DELPHI DCM7.1A TC297TP IROM PSA




DELPHI DCM7.1A TC297TP IROM PSA

DIRECT CONNECTION

In order to connect to the ECU use the cable F32GN037C/D.
Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
ROSSO RED	POSITIVO DIRETTO POWER BATTERY
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
NERO BLACK	MASSA GND
GIALLO YELLOW	KLINE
VERDE GREEN	CAN LOW
BIANCO WHITE	CAN HIGH
GRIGIO GREY	POL4 BOOT
BLU BLUE	POL5 CNF1
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE
MARRONE BROWN	RESET



WARNING:


Due to the relevant power absorbed by the ECU at the beginning of the communication it is necessary to feed the ECU with an external power supply or a car battery. Connect the power cable F32GN003 to the Trasdata and then to the power source.
The ECU must be powered through the Trasdata using the F32GN037C/D cable.

DELPHI DCM7.1A TC297TP IROM PSA

DIRECT BOOT&CNF1 CONNECTION

One of the BOOT pins is placed under the microprocessor


WARNING: we recommend using and tilting a metal support rod with a needle to reach the BOOT pin located under the microprocessor.



DELPHI DCM7.1A TC297TP IROM PSA

Connect the GREY&BLUE wires of the cable F32GN037C/D as shown in the picture.

COLORE FILO WIRE COLOUR		DESCRIZIONE DESCRIPTION
GRIGIO GREY		POL4 BOOT
BLU BLUE		POL5 CNF1



DELPHI DCM7.1A TC297TP IROM PSA

