
plugin 1357 DENSO MB275700-2753 SH7058 KOHLER Lay-by pins are placed in the lower side of the ECU.






DIRECT CONNECTION ECU TYPE 01

In order to connect to the ECU use the CABLE F32GN037C/D. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	CAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GH037C
BLU BLUE	POL5 CNF1	The same of the sa
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE	- CHANNA
MARRONE BROWN	RESET*	

ECU CONNECTOR



WARNING:


on this ECU you must use two different flat cables: one is for the READING procedure and one is for the WRITING procedure.

DIRECT CONNECTION - ECU READING:

For the READING procedure use the FLAT cable F34NTF53


	11 25 12 26	
Pin	Colore Colour	
	Non usato	
11	Not used	
12	Non usato	
Patricular	Not used Non usato	
13	Not used	
14	Non usato	
	Not used Non usato	
15	Not used	
16	Blu	
	Blue Viola	
17	Violet	
18	Grigio	
18	Grey	
19	Bianco White	
30	Nero	
20	Black	
21	Marrone Brown	
22	Rosso	
900	Red Arancio	
23	Orange Giallo	
24	Giallo Yellow	
	Verde	
25	Green	
26	Non usato Not used	


For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use fine grit glass-paper smoothing by gentle pressure the connection lay by pins.



ECU WRITING:

For a correct writing operation it is necessary to make the bridge with 1 resistor of 1 KOhm between 2 pads. Remove it before placing the ECU back into the vehicle.






DIRECT CONNECTION - ECU WRITING:

For the WRITING procedure use the FLAT cable F34NTF51

1 3 9 2 4 10		
Pin	Colore	
FIII	Colour	
1	Marrone	
*	Brown	
2	Non usato	
2 2 2 2 2	Not used	
3	Non usato	
	Not used Giallo	
4	Yellow	
-	Verde	
5	Green	
6	Blu	
b b	Blue	
7	Viola	
	Violet	
8	Grigio	
-	Grey	-
9	Bianco White	
20	Nero	
10	Black	


For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use fine grit glass-paper smoothing by gentle pressure the connection lay by pins.




METAL POSITIONING FRAME CONNECTION - ECU READING

Power the ECU with the F32GN037C/D wiring. Use the metal positioning frame adapter F34DM014.






WARNING: while connecting the adapter F34DM014 take care of the PIN1 assignment. Connect the pad marked as F34DM014 GND to the clamp GND on the F34DM014 adapter as shown in the following pictures





The following picture is merely indicative:



ECU TYPE 02 WRITING:


For a correct writing operation it is necessary to make the bridge with 1 resistor of 1 KOhm between 2 pads. Remove it before placing the ECU back into the vehicle.






METAL POSITIONING FRAME CONNECTION - ECU WRITING

Power the ECU with the F32GN037C/D wiring. Use the metal positioning frame adapter F34DM015.





The following picture is merely indicative:

