
plugin 412





DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	ICAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GN097C
BLU BLUE	POL5 CNF1	Bernandth)
	TENSIONE PROG. PROG. VOLTAGE	- CHANNED
MARRONE BROWN	RESET	

ECU CONNECTOR



WARNING :

on this ECU you must use two different flat cables: one is for the READING procedure and one is for the WRITING procedure.

DIRECT CONNECTION – ECU READING:

For the READING procedure use the FLAT cable F34NTF53

	1) 25 12 26	
Pin	Colore Colour	
11	Non usato	
Statistics	Not used Non usato	
12	Not used	
13	Non usato	
12	Not used	
14	Non usato	
	Not used Non usato	
15	Not used	
16	Blu	
16	Blue	
17	Viola	
	Violet Grigio	
18	Grey	
10	Bianco	
19	White	
20	Nero	
	Black	
21	Marrone	
	Brown	
22	Rosso	
	Red Arancio	
23	Orange	
24	Giallo	
24	Yellow	
25	Verde Green	
	Non usato	
26	Not used	

For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use a fine grit glass-paper smoothing by gentle pressure the connection of the lay by pins.



DIRECT CONNECTION – ECU WRITING:

For the WRITING procedure use the FLAT cable F34NTF51


1 3 9 2 4 10		
Pin	Colore	
	Colour	
1	Marrone	
	Brown	
2.	Non usato	
	Not used	
3	Non usato	
	Not used Giallo	
4	Yellow	
	Verde	
5	Green	
	Blu	
6	Blue	
-	Viola	
7	Violet	
8	Grigio	
0	Grey	and the second s
9	Bianco	all and a second
	White	and in the set of the
10	Nero	
±0	Black	


For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use a fine grit glass-paper smoothing by gentle pressure the connection of the lay by pins.



DIMA CONNECTION – ECU READING

Power the ECU with the F32GN037C wiring. Use the DIMA adapter F34DM016.





DIMA CONNECTION – ECU WRITING

Power the ECU with the F32GN037C wiring. Use the DIMA adapter F34DM019.

