**PLUGIN 264,265,277,278,294**The lay-by pins are placed in the lower part of the ECU.






#### **DIRECT CONNECTION**

In order to connect to the ECU use the CABLE F32GN037C. Make sure that the POWER led (red) on Trasdata is ON. Use the same connection for the DIMA too.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION	
ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
NERO BLACK	MASSA GND	
GIALLO YELLOW	KLINE	
VERDE GREEN	CAN LOW	
BIANCO WHITE	CAN HIGH	
GRIGIO GREY	POL4 BOOT	F32GM337C
BLU BLUE	POLS CNF1	Barranill   6999
	TENSIONE PROG. PROG. VOLTAGE	THE SAME OF THE SA
MARRONE BROWN	RESET	

#### **ECU CONNECTOR**



#### WARNING:


on this ECU you must use two different flat cables: one is for the READING procedure and one is for the WRITING procedure.

### **DIRECT CONNECTION – ECU READING:**

For the READING procedure use the FLAT cable F34NTF53


The second secon	25 12 26	
Pin	Colore	
5111	Colour	
11	Non usato	
Market III	Not used Non usato	
12	Not used	
10	Non usato	
13	Not used	
14	Non usato	
	Not used Non usato	
15	Not used	
16	Blu	
10	Blue	
17	Viola	
	Violet Grigio	
18	Grey	
19	Bianco	
19	White	
20	Nero	
	Black	
21	Marrone	
	Brown	
22	Rosso	
Brew	Red Arancio	
23	Orange	
24	Giallo	
6000	Yellow Verde	
25	Green	
26	Non usato	
26	Not used	

For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use fine grit glass-paper smoothing by gentle pressure The connection lay by pins.




#### **DIRECT CONNECTION - ECU WRITING:**

For the WRITING procedure use the FLAT cable F34NTF51





For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use fine grit glass-paper smoothing by gentle pressure the connection lay by pins.



### **DIMA CONNECTION - ECU READING**

Power the ECU with the F32GN037C wiring. Use the DIMA adapter F34DM016.







### **DIMA CONNECTION - ECU WRITING**

Power the ECU with the F32GN037C wiring. Use the DIMA adapter DIMA F34DM019.

