
plugin 606 -1750








DIRECT CONNECTION

In order to connect to the ECU use the CABLE F32GN037C/D Make sure that the POWER led (red) on Trasdata is ON.

and the second second	RE FILO COLOUR	DESCRIZIONE DESCRIPTION	
	ROSSO RED	POSITIVO DIRETTO POWER BATTERY	
	ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON	
2	NERO BLACK	MASSA GND	
	GIALLO YELLOW	KLINE	
	VERDE GREEN	CAN LOW	
	BIANCO WHITE	CAN HIGH	
	GRIGIO GREY	POL4 BOOT	
	BLU BLUE	POL5 CNF1	
Ť.		TENSIONE PROG. PROG. VOLTAGE	
	MARRONE BROWN	RESET	



ECU CONNECTOR



WARNING:

on this ECU you must use two different flat cables: one is for the READING procedure and one is for the WRITING procedure


DIRECT CONNECTION - ECU READING:

For the READING procedure use the FLAT cable F34NTF53

	1 25 2 26	
Pin	Colore Coulor	
11	Non usato Not used	
12	Non usato Not used	
13	Non usato Not used	
14	Non usato Not used	
15	Non usato Not used	
16	Blu Blue	
17	Non usato Not used	
18	Grigio Grey	
19	Bianco White	A N
20	Nero Black	
21	Marrone Brown	
22	Rosso Red	
23	Arancio Orange Giallo	
24	Yellow Verde	
25	Green Non usato	
26	Not used	

For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use a fine grit glass-paper smoothing by gentle pressure the connection of the lay by pins.

For a correct reading operation you need to perform the 4 LINK as in the picture here below.



DIRECT CONNECTION - ECU WRITING:

For the WRITING procedure use the FLAT cable F34NTF51

1 3 9 2 4 10		
Pin	Colore	
PIII	Colour	
1	Marrone	
*	Brown	
2.	Non usato	
	Not used	
3	Non usato	
2000	Not used Non usato	
4	Not used	
_	Verde	
5	Green	
-	Blu	
6	Blue	
7	Viola	
/	Violet	
8	Grigio	
	Grey	
9	Non usato	and the same of
	Not used	and the same of th
10	Nero	
- 	Black	

For a correct soldering procedure clean very well the soldering lay-by pins from the plastic film. We suggest you to use a fine grit glass-paper smoothing by gentle pressure the connection of the lay by pins.

