


SIEMENS PCR2.1 IROM TC1796 SSM BENCH VAG

plugin 1550



## SIEMENS PCR2.1 IROM TC1796 SSM BENCH VAG

### SSM CONNECTION


In order to use the SSM connection it is necessary to use both the ANALOG PORT and the DIGITAL PORT of the Trasdata.

### LOOSE WIRES SSM CONNECTION

Connect the F32GN037C/D cable to the **ANALOG PORT**

Connect the F34NTA18 cable to the **DIGITAL PORT**

### F34NTA18




## SIEMENS PCR2.1 IROM TC1796 SSM BENCH VAG

### DIRECT CONNECTION

In order to connect to the ECU use the cable F32GN037C/D.  
 Make sure that the POWER led (red) on Trasdata is ON.

COLORE FILO WIRE COLOUR	DESCRIZIONE DESCRIPTION
ROSSO RED	POSITIVO DIRETTO POWER BATTERY
ARANCIO ORANGE	POSITIVO SOTTO QUADRO POWER SWITCH ON
NERO BLACK	MASSA GND
GIALLO YELLOW	KLINE
VERDE GREEN	CAN LOW
BIANCO WHITE	CAN HIGH
GRIGIO GREY	POL4 BOOT
BLU BLUE	POL5 CNF1
VIOLA/GRIGIO PURPLE/GREY	TENSIONE PROG. PROG. VOLTAGE
MARRONE BROWN	RESET



### ECU CONNECTOR

Perform the connections using F32GN037C/D and F34NTA18 as described here below:

PIN / Colore PIN / Color	DESCRIZIONE DESCRIPTION
	SSM_S1
	SSM_S2

